aiwa
SERVICE

CSD-A190 EZ(S,ST),K(ST)

SERVICE MANUAL

CD STEREO RADIO
CASSETTE RECORDER

BASIC TAPE MECHANISM : TN-21ZVC-2000
BASIC CD MECHANISM : KSM-213RDM

• Replace this Service Manual with “Revision Publishing” when it is issued.

aiwa

S/M Code No. 09-023-457-0T1

SIMPLE DATA

ELECTRICAL PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL		
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
CD		X	C 0402	88-214-840-010	CAP,CER 0.033-50 M YY	a	b	c
CD		X	C 0403	88-211-522-080	CAP,CER 330P-50 J SL	a	b	c
CD		O	C 0404	87-010-544-080	CAP,E 0.1-50 M 11L SME	a	b	c
CD		X	C 0405	88-214-840-010	CAP,CER 0.033-50 M YY	a	b	c
CD		O	C 0406	87-A10-210-010	CAP,CER 0.047-50 M	a	b	c
CD		O	C 0407	87-A10-579-010	CAP,CER 0.1-16 Z YF	a	b	c
CD		O	C 0409	87-A10-176-010	CAP,CER 1000P-50 K B	a	b	c
CD		O	C 0410	87-A10-579-010	CAP,CER 0.1-16 Z YF	a	b	c
CD		X	C 0411	88-214-840-010	CAP,CER 0.033-50 M YY	a	b	c
CD		O	C 0412	87-A10-179-010	CAP,CER 3300P-50 M E	a	b	c
CD		O	C 0413	87-010-545-080	CAP,E 0.22-50 M 11L SME	a	b	c
CD		X	C 0414	88-211-412-080	CAP,CER 100P-50 J SL	a	b	c
CD		O	C 0415	87-A10-179-010	CAP,CER 3300P-50 M E	a	b	c
CD		O	C 0416	87-010-400-010	CAP,E 0.47-50 M SME	a	b	c
CD		O	C 0417	87-010-263-080	CAP,E 100-10 M 11L SME	a	b	c
CD		O	C 0418	87-A10-579-010	CAP,CER 0.1-16 Z YF	a	b	c
CD		X	C 0420	88-254-150-010	CAP,CER 15P-50 J CH	a	b	c
CD		O	C 0421	87-A12-356-080	CAP,M 2200P-100 J CP	a	b	c
CD		X	C 0422	88-214-840-010	CAP,CER 0.033-50 M YY	a	b	c
CD		O	C 0423	87-010-405-080	CAP,E 10-50 M 11L SME	a	b	c

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL		
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
CD		O	C 0424	87-010-405-080	CAP,E 10-50 M 11L SME	a	b	c
CD		O	C 0425	87-A10-181-010	CAP,CER 6800P-50 M E	a	b	c
CD		O	C 0426	87-A10-210-010	CAP,CER 0.047-50 M	a	b	c
CD		O	C 0427	87-010-546-080	CAP,E 0.33-50 M 11L SME	a	b	c
CD		O	C 0428	87-A10-182-010	CAP,CER 0.01-50 Z F	a	b	c
CD		O	C 0429	87-010-263-080	CAP,E 100-10 M 11L SME	a	b	c
CD		O	C 0430	87-010-260-080	CAP,E 47-25 M 11L SME	a	b	c
CD		O	C 0431	87-A10-176-010	CAP,CER 1000P-50 K B	a	b	c
CD		O	C 0432	87-010-263-080	CAP,E 100-10 M 11L SME	a	b	c
CD		O	C 0433	87-A10-182-010	CAP,CER 0.01-50 Z F	a	b	c
CD		O	C 0434	87-A10-182-010	CAP,CER 0.01-50 Z F	a	b	c
CD		O	C 0435	87-010-263-080	CAP,E 100-10 M 11L SME	a	b	c
CD		O	C 0436	87-A10-577-010	CAP,CER 0.022-50 Z YF	a	b	c
CD		O	C 0437	87-010-248-080	CAP,E 220-10 M 11L SME	a	b	c
CD		O	C 0438	87-A10-579-010	CAP,CER 0.1-16 Z YF	a	b	c
CD		O	C 0439	87-010-405-080	CAP,E 10-50 M 11L SME	a	b	c
CD		O	C 0440	87-010-237-080	CAP,E 1000-16 M SME	a	b	c
CD		O	C 0441	87-010-221-080	CAP,E 470-10 M SME	a	b	c
CD		O	C 0442	87-A10-182-010	CAP,CER 0.01-50 Z F	a	b	c
CD		X	C 0443	88-254-240-010	CAP,CER 30P-50 J C	a	b	c

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL		
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
CD		X	C 0444	88-254-240-010	CAP,CER 30P-50 J C	a	b	c
CD		O	C 0445	87-A10-577-010	CAP,CER 0.022-50 Z YF	a	b	c
CD		O	C 0446	87-A12-380-080	CAP,M 0.22-100 J CP	a	b	c
CD		O	C 0447	87-A10-579-010	CAP,CER 0.1-16 Z YF	a	b	c
CD		O	C 0448	87-A10-580-010	CAP,CER 0.22-16 Z YF	a	b	c
CD		X	C 0448	88-211-412-080	CAP,CER 100P-50 J SL	a	b	c
CD		O	C 0449	87-A10-182-010	CAP,CER 0.01-50 Z F	a	b	c
CD		O	C 0450	87-010-263-080	CAP,E 100-10 M 11L SME	a	b	c
CD		O	C 0451	87-010-386-080	CAP,E 330-25 M SME	a	b	c
CD		O	C 0452	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
CD		O	C 0455	87-010-403-080	CAP,E 3.3-50 M 11L SME	a	b	c
CD		O	C 0456	87-010-403-080	CAP,E 3.3-50 M 11L SME	a	b	c
CD		X	C 0457	88-211-552-080	CAP,CER 470P-50 J SL	a	b	c
CD		X	C 0458	88-211-552-080	CAP,CER 470P-50 J SL	a	b	c
CD		X	C 0459	88-211-572-010	CAP,CER 680P-50 J SL	a	b	c
CD		O	C 0461	87-010-403-080	CAP,E 3.3-50 M 11L SME	a	b	c
CD		O	C 0463	87-010-221-080	CAP,E 470-10 M SME	a	b	c
CD		O	C 0469	87-A10-182-010	CAP,CER 0.01-50 Z F	a	b	c
CD		O	C 0478	87-010-405-080	CAP,E 10-50 M 11L SME	a	b	c
CD		O	C 0701	87-A10-579-010	CAP,CER 0.1-16 Z YF	a	b	c

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL		
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
CD		O	CN 0401	8B-CDC-660-010	CONN,16P V TOC-B	a	b	c
CD		O	CN 0402	8B-CDC-661-010	CONN ASSY,6P CD-ME	a	b	c
CD		O	CN 0403	8B-CDC-663-010	F-CABLE ASSY,5P 2 153MM	a	b	c
CD		O	CN 0404	87-A60-633-010	CONN,2P H 2.5MM JMT	a	b	c
CD		O	CN 0405	8B-CDC-664-010	F-CABLE ASSY,8P 2 153MM	a	b	c
CD		S	D 0401	8B-CDC-622-010	DIODE,GMB01	a	b	c
CD		S	D 0401	8B-CDC-631-010	ZENER,BZX55C6V8CECCL	a	b	c
CD		S	D 0402	87-070-345-080	DIODE,1N4148	a	b	c
CD		S	D 0403	87-070-345-080	DIODE,1N4148	a	b	c
CD		S	D 0411	87-070-345-080	DIODE,1N4148	a	b	c
CD		S	D 0418	87-070-345-080	DIODE,1N4148	a	b	c
CD		O	D 0501	8B-CDC-624-010	LED,A505RDD	a	b	c
CD		S	D 0505	87-070-345-080	DIODE,1N4148	a	b	c
CD		S	D 0506	87-070-345-080	DIODE,1N4148	a	b	c
CD		S	D 0507	87-070-345-080	DIODE,1N4148	a	b	c
CD		S	D 0508	87-070-345-080	DIODE,1N4148	a	b	c
CD		S	D 0509	87-070-345-080	DIODE,1N4148	a	b	c
CD		S	D 0510	87-070-345-080	DIODE,1N4148	a	b	c
CD		O	D 0905	87-070-106-010	LED,SE3001DT R	a	b	c
CD		S	IC 0401	8C-CDC-611-010	C-IC,LA9251M	a	b	c

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL		
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
CD		S	IC 0402	8C-CDC-610-010	C-IC,LC78602HKE	a	b	c
CD		S	IC 0403	87-A21-093-010	IC,LA6541D	a	b	c
CD		O	L 0401	87-005-849-080	COIL,10UH K CECS	a	b	c
CD		S	Q 0401	87-A30-015-080	TR,2SA1317(T/U)	a	b	c
CD		S	Q 0402	8B-CDC-613-010	TR,2SA1346	a	b	c
CD		S	Q 0403	8B-CDC-614-010	TR,2SB764	a	b	c
CD		S	Q 0404	8A-RU2-604-010	TR,3CA8550	a	b	c
CD		S	Q 0405	8A-RU2-604-010	TR,3CA8550	a	b	c
CD		S	Q 0408	8B-CDC-613-010	TR,2SA1346	a	b	c
CD		X	R 0401	88-121-563-080	RES,56K-1/8W J	a	b	c
CD		X	R 0402	88-121-563-080	RES,56K-1/8W J	a	b	c
CD		X	R 0403	88-121-563-080	RES,56K-1/8W J	a	b	c
CD		X	R 0404	88-121-563-080	RES,56K-1/8W J	a	b	c
CD		X	R 0405	88-121-104-080	RES,100K-1/8W J	a	b	c
CD		X	R 0406	88-121-104-080	RES,100K-1/8W J	a	b	c
CD		X	R 0408	88-121-392-080	RES,3.9K-1/8W J	a	b	c
CD		X	R 0409	88-121-222-080	RES,2.2K-1/8W J	a	b	c
CD		X	R 0410	88-121-331-080	RES,330-1/8W J	a	b	c
CD		X	R 0411	88-121-563-080	RES,56K-1/8W J	a	b	c
CD		X	R 0412	88-121-153-080	RES,15K-1/8W J	a	b	c

						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
CD		X	R 0413	88-121-223-080	RES,22K-1/8W J	a	b	c
CD		X	R 0414	88-121-104-080	RES,100K-1/8W J	a	b	c
CD		X	R 0415	88-121-105-080	RES,1M-1/8W J	a	b	c
CD		X	R 0416	88-121-222-080	RES,2.2K-1/8W J	a	b	c
CD		X	R 0417	88-121-333-080	RES,33K-1/8W J	a	b	c
CD		X	R 0418	88-121-223-080	RES,22K-1/8W J	a	b	c
CD		X	R 0419	88-121-153-080	RES,15K-1/8W J	a	b	c
CD		X	R 0420	88-121-223-080	RES,22K-1/8W J	a	b	c
CD		X	R 0421	88-121-152-080	RES,1.5K-1/8W J	a	b	c
CD		X	R 0422	88-121-223-080	RES,22K-1/8W J	a	b	c
CD		X	R 0423	88-121-333-080	RES,33K-1/8W J	a	b	c
CD		X	R 0424	88-121-563-080	RES,56K-1/8W J	a	b	c
CD		X	R 0425	88-121-563-080	RES,56K-1/8W J	a	b	c
CD		X	R 0426	88-121-102-080	RES,1K-1/8W J	a	b	c
CD		X	R 0427	88-121-103-080	RES,10K-1/8W J	a	b	c
CD		X	R 0428	88-121-153-080	RES,15K-1/8W J	a	b	c
CD		X	R 0429	88-121-394-080	RES,390K-1/8W J	a	b	c
CD		X	R 0430	88-121-273-080	RES,27K-1/8W J	a	b	c
CD		X	R 0431	88-121-224-080	RES,220K-1/8W J	a	b	c
CD		X	R 0432	88-121-224-080	RES,220K-1/8W J	a	b	c

						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
CD		X	R 0433	88-121-103-080	RES,10K-1/8W J	a	b	c
CD		X	R 0434	88-121-562-080	RES,5.6K-1/8W J	a	b	c
CD		X	R 0435	88-121-153-080	RES,15K-1/8W J	a	b	c
CD		X	R 0436	88-121-103-080	RES,10K-1/8W J	a	b	c
CD		X	R 0437	88-121-272-080	RES,2.7K-1/8W J	a	b	c
CD		X	R 0438	88-121-333-080	RES,33K-1/8W J	a	b	c
CD		X	R 0439	88-121-102-080	RES,1K-1/8W J	a	b	c
CD		X	R 0440	88-121-331-080	RES,330-1/8W J	a	b	c
CD		X	R 0441	88-121-472-080	RES,4.7K-1/8W J	a	b	c
CD		X	R 0442	88-121-564-080	RES,560K-1/8W J	a	b	c
CD		X	R 0443	88-121-101-080	RES,100-1/8W J	a	b	c
CD		X	R 0444	88-121-220-080	RES,22-1/8W J	a	b	c
CD		X	R 0445	88-121-471-080	RES,470-1/8W J	a	b	c
CD		X	R 0446	88-121-153-080	RES,15K-1/8W J	a	b	c
CD		X	R 0447	88-121-103-080	RES,10K-1/8W J	a	b	c
CD		X	R 0448	88-121-104-080	RES,100K-1/8W J	a	b	c
CD		X	R 0449	88-121-103-080	RES,10K-1/8W J	a	b	c
CD		X	R 0450	88-121-333-080	RES,33K-1/8W J	a	b	c
CD		X	R 0451	88-121-333-080	RES,33K-1/8W J	a	b	c
CD		X	R 0452	88-121-272-080	RES,2.7K-1/8W J	a	b	c

						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
CD		X	R 0453	88-121-272-080	RES,2.7K-1/8W J	a	b	c
CD		X	R 0457	88-121-101-080	RES,100-1/8W J	a	b	c
CD		X	R 0458	88-121-101-080	RES,100-1/8W J	a	b	c
CD		X	R 0459	88-121-101-080	RES,100-1/8W J	a	b	c
CD		X	R 0460	88-121-101-080	RES,100-1/8W J	a	b	c
CD		X	R 0461	88-121-101-080	RES,100-1/8W J	a	b	c
CD		X	R 0462	88-121-101-080	RES,100-1/8W J	a	b	c
CD		X	R 0463	88-121-101-080	RES,100-1/8W J	a	b	c
CD		X	R 0464	88-121-101-080	RES,100-1/8W J	a	b	c
CD		X	R 0465	88-121-392-080	RES,3.9K-1/8W J	a	b	c
CD		X	R 0466	88-121-392-080	RES,3.9K-1/8W J	a	b	c
CD		X	R 0467	88-121-473-080	RES,47K-1/8W J	a	b	c
CD		X	R 0469	88-121-473-080	RES,47K-1/8W J	a	b	c
CD		X	R 0470	88-121-103-080	RES,10K-1/8W J	a	b	c
CD		X	R 0907	88-121-332-080	RES,3.3K-1/8W J	a	b	c
CD		X	R 0908	88-121-562-080	RES,5.6K-1/8W J	a	b	c
CD		O	SW 0402	8B-CDC-623-010	SW,TACT 1102B160G	a	b	c
CD		O	SW 0403	8B-CDC-623-010	SW,TACT 1102B160G	a	b	c
CD		O	SW 0404	8B-CDC-623-010	SW,TACT 1102B160G	a	b	c
CD		O	SW 0405	8B-CDC-623-010	SW,TACT 1102B160G	a	b	c

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL		
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
CD		O	SW 0406	8B-CDC-623-010	SW,TACT 1102B160G	a	b	c
CD		O	SW 0407	8B-CDC-623-010	SW,TACT 1102B160G	a	b	c
CD		O	SW 0501	87-A90-050-010	SW,SL 2-2-2 NS (BLK)	a	b	c
CD		O	X 0401	8Z-CD5-633-010	VIB, CER16.93MHZ FCR16.93M2	a	b	c
OTHERS		X	JW 0001	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0002	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0003	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0004	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0005	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0006	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0007	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0008	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0009	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0010	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0011	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0012	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0013	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0015	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0016	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0017	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
OTHERS		X	JW 0019	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0020	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0021	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0022	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0023	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0024	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0025	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0026	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0027	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0028	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0030	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0031	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0032	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0033	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0034	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0035	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0036	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0037	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0039	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0040	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
OTHERS		X	JW 0041	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0044	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0046	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0048	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0051	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0052	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0054	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0057	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0058	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0059	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0060	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0061	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0062	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0063	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0069	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0074	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0077	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0079	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0085	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0086	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
OTHERS		X	JW 0087	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0088	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0089	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0091	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0092	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0093	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0094	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0095	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0098	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0099	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0100	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0101	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0102	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0103	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0104	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0105	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0106	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0107	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0108	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0109	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
OTHERS		X	JW 0110	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0111	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
OTHERS		X	JW 0112	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
POWER		O	C 0601	87-A10-182-010	CAP,CER 0.01-50 Z F	a	b	c
POWER		O	C 0602	87-A10-182-010	CAP,CER 0.01-50 Z F	a	b	c
POWER		O	C 0603	87-A10-182-010	CAP,CER 0.01-50 Z F	a	b	c
POWER		O	C 0604	87-A10-182-010	CAP,CER 0.01-50 Z F	a	b	c
POWER		O	C 0605	87-010-388-080	CAP,E 1000-25 M SME	a	b	c
POWER		O	CNA0601	8C-CDC-620-010	CONN ASSY,2P POWER	a	b	c
POWER		S	D 0601	87-A40-398-010	DIODE,1N4001	a	b	c
POWER		S	D 0602	87-A40-398-010	DIODE,1N4001	a	b	c
POWER		S	D 0604	87-A40-398-010	DIODE,1N4001	a	b	c
POWER		S	D 6036	87-A40-398-010	DIODE,1N4001	a	b	c
POWER AMP		O	C 0801	87-018-127-080	CAP,TC U 470P-50 K B UP050	a	b	c
POWER AMP		O	C 0802	87-018-127-080	CAP,TC U 470P-50 K B UP050	a	b	c
POWER AMP		O	C 0805	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
POWER AMP		O	C 0806	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
POWER AMP		O	C 0809	87-010-260-080	CAP,E 47-25 M 11L SME	a	b	c
POWER AMP		O	C 0810	87-010-260-080	CAP,E 47-25 M 11L SME	a	b	c
POWER AMP		O	C 0817	87-010-386-080	CAP,E 330-25 M SME	a	b	c
POWER AMP		O	C 0819	87-010-405-080	CAP,E 10-50 M 11L SME	a	b	c
POWER AMP		O	C 0820	87-010-388-080	CAP,E 1000-25 M SME	a	b	c
POWER AMP		O	C 0824	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
POWER AMP		O	C 0828	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
POWER AMP		O	C 0829	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
POWER AMP		O	C 0858	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
POWER AMP		O	C 0859	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
POWER AMP		O	C 0872	87-010-263-080	CAP,E 100-10 M 11L SME	a	b	c
POWER AMP		O	C 0874	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
POWER AMP		O	C 0877	87-A10-304-080	CAP,M 0.056-50 J	a	b	c
POWER AMP		O	C 0878	87-A10-304-080	CAP,M 0.056-50 J	a	b	c
POWER AMP		X	C 0887	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
POWER AMP		X	C 0888	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
POWER AMP		O	CN 0801	8B-CDC-657-010	CONN,4P V SPK-OUT	a	b	c
POWER AMP		O	CN 0802	8B-CDC-657-010	CONN,4P V SPK-OUT	a	b	c
POWER AMP		S	IC 0801	87-A21-193-010	IC,TA8227P	a	b	c
POWER AMP		S	Q 0801	89-318-155-080	TR,2SC1815GR	a	b	c
POWER AMP		S	Q 0802	89-318-155-080	TR,2SC1815GR	a	b	c
POWER AMP		S	Q 0803	89-318-155-080	TR,2SC1815GR	a	b	c
POWER AMP		S	Q 0804	89-318-155-080	TR,2SC1815GR	a	b	c
POWER AMP		S	Q 0807	89-318-155-080	TR,2SC1815GR	a	b	c
POWER AMP		S	Q 0808	89-318-155-080	TR,2SC1815GR	a	b	c
POWER AMP		X	R 0470	88-121-101-080	RES,100-1/8W J	a	b	c
POWER AMP		X	R 0801	88-121-332-080	RES,3.3K-1/8W J	a	b	c
POWER AMP		X	R 0802	88-121-103-080	RES,10K-1/8W J	a	b	c
POWER AMP		X	R 0803	88-121-103-080	RES,10K-1/8W J	a	b	c
POWER AMP		X	R 0804	88-121-332-080	RES,3.3K-1/8W J	a	b	c
POWER AMP		X	R 0805	88-121-102-080	RES,1K-1/8W J	a	b	c
POWER AMP		X	R 0806	88-121-102-080	RES,1K-1/8W J	a	b	c
POWER AMP		X	R 0807	88-121-102-080	RES,1K-1/8W J	a	b	c
POWER AMP		X	R 0808	88-121-102-080	RES,1K-1/8W J	a	b	c
POWER AMP		X	R 0821	88-121-104-080	RES,100K-1/8W J	a	b	c
POWER AMP		X	R 0822	88-121-104-080	RES,100K-1/8W J	a	b	c
POWER AMP		X	R 0825	88-121-562-080	RES,5.6K-1/8W J	a	b	c
POWER AMP		X	R 0826	88-121-103-080	RES,10K-1/8W J	a	b	c
POWER AMP		X	R 0828	88-121-103-080	RES,10K-1/8W J	a	b	c
POWER AMP		X	R 0829	88-121-102-080	RES,1K-1/8W J	a	b	c
POWER AMP		X	R 0830	88-121-102-080	RES,1K-1/8W J	a	b	c
POWER AMP		X	R 0848	88-121-223-080	RES,22K-1/8W J	a	b	c
POWER AMP		X	R 0849	88-121-223-080	RES,22K-1/8W J	a	b	c
POWER AMP		X	R 0855	88-121-104-080	RES,100K-1/8W J	a	b	c
POWER AMP		X	R 0856	88-121-104-080	RES,100K-1/8W J	a	b	c
POWER AMP		X	R 0857	88-121-473-080	RES,47K-1/8W J	a	b	c
POWER AMP		X	R 0858	88-121-473-080	RES,47K-1/8W J	a	b	c
POWER AMP		X	R 0859	88-121-222-080	RES,2.2K-1/8W J	a	b	c
POWER AMP		X	R 0860	88-121-222-080	RES,2.2K-1/8W J	a	b	c
POWER AMP		X	R 0861	88-121-102-080	RES,1K-1/8W J	a	b	c
POWER AMP		X	R 0862	88-121-102-080	RES,1K-1/8W J	a	b	c
POWER AMP		X	R 0865	88-121-562-080	RES,5.6K-1/8W J	a	b	c
POWER AMP		X	R 0866	88-121-562-080	RES,5.6K-1/8W J	a	b	c
POWER AMP		X	R 0867	88-121-152-080	RES,1.5K-1/8W J	a	b	c
POWER AMP		X	R 0868	88-121-152-080	RES,1.5K-1/8W J	a	b	c
POWER AMP		X	R 0872	88-121-101-080	RES,100-1/8W J	a	b	c
POWER AMP		O	S 0801	87-A91-884-010	SW,SL-4-4 SK44D01G6A	a	b	c
POWER AMP		O	VR 0802	8A-RU2-661-010	VR,RTRY 50KCX2 XV012302GP	a	b	c
POWER SUPPLY		O	C 0901	87-010-263-080	CAP,E 100-10 M 11L SME	a	b	c
POWER SUPPLY		O	CN 0901	8B-CDC-658-010	CONN,3P V BATT	a	b	c
POWER SUPPLY		S	D 0203	87-070-345-080	DIODE,1N4148	a	b	c
POWER SUPPLY		S	D 0301	87-070-345-080	DIODE,1N4148	a	b	c
POWER SUPPLY		S	D 0855	87-070-345-080	DIODE,1N4148	a	b	c

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
POWER SUPPLY		S D	0856	87-070-345-080	DIODE,1N4148	a	b	c
POWER SUPPLY		S D	0901	87-070-345-080	DIODE,1N4148	a	b	c
POWER SUPPLY		S D	0903	8B-CDC-631-010	ZENER,BZX55C6V8CECCL	a	b	c
POWER SUPPLY		S D	0904	87-070-345-080	DIODE,1N4148	a	b	c
POWER SUPPLY		X L	0801	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
POWER SUPPLY		X L	0802	88-100-000-010	PLATING-JW, 0.58 SN95	a	b	c
POWER SUPPLY		S Q	0851	87-A30-168-010	TR,2SB1566F	a	b	c
POWER SUPPLY		S Q	0852	8A-RU2-602-010	TR,3DA8050	a	b	c
POWER SUPPLY		S Q	0901	8B-CDC-678-010	TR,AN1L3Z	a	b	c
POWER SUPPLY		S Q	0902	8B-CDC-678-010	TR,AN1L3Z	a	b	c
POWER SUPPLY		X R	0217	88-121-103-080	RES,10K-1/8W J	a	b	c
POWER SUPPLY		X R	0851	88-121-103-080	RES,10K-1/8W J	a	b	c
POWER SUPPLY		X R	0852	88-121-471-080	RES,470-1/8W J	a	b	c
POWER SUPPLY		X R	0853	88-121-682-080	RES,6.8K-1/8W J	a	b	c
POWER SUPPLY		X R	0901	88-121-471-080	RES,470-1/8W J	a	b	c
POWER SUPPLY		X R	0902	88-121-103-080	RES,10K-1/8W J	a	b	c
POWER SUPPLY		X R	0904	88-121-471-080	RES,470-1/8W J	a	b	c
POWER SUPPLY		X R	0906	88-121-221-080	RES,220-1/8W J	a	b	c
TAPE		O C	0303	87-010-404-080	CAP,E 4.7-50 M 11L SME	a	b	c
TAPE		O C	0305	87-A12-369-080	CAP,M 0.027-100 J CP	a	b	c

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
TAPE		O C	0306	87-010-405-080	CAP,E 10-50 M 11L SME	a	b	c
TAPE		O C	0307	87-010-404-080	CAP,E 4.7-50 M 11L SME	a	b	c
TAPE		O C	0312	87-A12-369-080	CAP,M 0.027-100 J CP	a	b	c
TAPE		O C	0313	87-A12-356-080	CAP,M 2200P-100 J CP	a	b	c
TAPE		O C	0315	87-A12-356-080	CAP,M 2200P-100 J CP	a	b	c
TAPE		O C	0390	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
TAPE		O C	0391	87-010-405-080	CAP,E 10-50 M 11L SME	a	b	c
TAPE		O C	0392	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
TAPE		O CN	0301	8B-CDC-659-010	CONN,4P V T-HEAD	a	b	c
TAPE		S IC	0301	87-A20-569-010	IC,BA3308	a	b	c
TAPE		X R	0300	88-121-472-080	RES,4.7K-1/8W J	a	b	c
TAPE		X R	0301	88-121-823-080	RES,82K-1/8W J	a	b	c
TAPE		X R	0302	88-121-224-080	RES,220K-1/8W J	a	b	c
TAPE		X R	0303	88-121-823-080	RES,82K-1/8W J	a	b	c
TAPE		X R	0305	88-121-820-080	RES,82-1/8W J	a	b	c
TAPE		X R	0306	88-121-472-080	RES,4.7K-1/8W J	a	b	c
TAPE		X R	0307	88-121-472-080	RES,4.7K-1/8W J	a	b	c
TAPE		X R	0308	88-121-820-080	RES,82-1/8W J	a	b	c
TAPE		X R	0309	88-121-472-080	RES,4.7K-1/8W J	a	b	c
TAPE		X R	0310	88-121-682-080	RES,6.8K-1/8W J	a	b	c

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
TAPE		X R	0311	88-121-123-080	RES,12K-1/8W J	a	b	c
TAPE		X R	0312	88-121-102-080	RES,1K-1/8W J	a	b	c
TAPE		X R	0313	88-121-472-080	RES,4.7K-1/8W J	a	b	c
TAPE		X R	0314	88-121-123-080	RES,12K-1/8W J	a	b	c
TAPE		X R	0315	88-121-123-080	RES,12K-1/8W J	a	b	c
TAPE		X R	0316	88-121-102-080	RES,1K-1/8W J	a	b	c
TAPE		X R	0317	88-121-123-080	RES,12K-1/8W J	a	b	c
TAPE		X R	0323	88-121-682-080	RES,6.8K-1/8W J	a	b	c
TAPE		X R	0390	88-121-123-080	RES,12K-1/8W J	a	b	c
TAPE		X R	0397	88-121-123-080	RES,12K-1/8W J	a	b	c
TAPE		O SW	0302	8B-CDC-635-010	SW,SL 1-9-2 PS92D01	a	b	c
TUNER		X C	0201	88-254-230-010	CAP,CER 27P-50 CH	a	b	c
TUNER		O C	0202	87-A10-139-010	CAP,CER 18P-50 K CH	a	b	c
TUNER		O C	0203	87-010-400-010	CAP,E 0.47-50 M SME	a	b	c
TUNER		O C	0204	87-010-265-080	CAP,E 33-16 M 11L SME	a	b	c
TUNER		O C	0205	8Z-CA3-613-010	CAP,CER 0.02-50	a	b	c
TUNER		O C	0206	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
TUNER		O C	0207	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
TUNER		O C	0208	87-A10-182-010	CAP,CER 0.01-50 Z F	a	b	c
TUNER		O C	0209	87-A10-182-010	CAP,CER 0.01-50 Z F	a	b	c

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
TUNER		O C	0210	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
TUNER		O C	0211	87-010-544-080	CAP,E 0.1-50 M 11L SME	a	b	c
TUNER		O C	0212	87-010-544-080	CAP,E 0.1-50 M 11L SME	a	b	c
TUNER		O C	0213	87-010-545-080	CAP,E 0.22-50 M 11L SME	a	b	c
TUNER		O C	0214	87-A10-176-010	CAP,CER 1000P-50 K B	a	b	c
TUNER		O C	0215	87-A10-130-010	CAP,CER 4P-50 K CH	a	b	c
TUNER		O C	0216	87-A10-133-010	CAP,CER 7P-50 K CH	a	b	c
TUNER		O C	0217	87-A10-127-010	CAP,CER 1P-50 K CH	a	b	c
TUNER		O C	0218	8Z-CA3-613-010	CAP,CER 0.02-50	a	b	c
TUNER		O C	0220	8B-CS9-628-010	CAP,CER 130P-50 J NPO	a	b	c
TUNER		O C	0221	87-A10-136-010	CAP,CER 10P-50 K CH	a	b	c
TUNER		O C	0222	87-010-248-010	CAP,E 220-10 M SME	a	b	c
TUNER		O C	0223	87-010-248-010	CAP,E 220-10 M SME	a	b	c
TUNER		O C	0224	87-A10-138-010	CAP,CER 15P-50 K CH	a	b	c
TUNER		O C	0225	87-A10-579-010	CAP,CER 0.1-16 Z YF	a	b	c
TUNER		O C	0227	87-010-401-080	CAP,E 1-50 M 11L SME	a	b	c
TUNER		O C	0228	8Z-CA3-613-010	CAP,CER 0.02-50	a	b	c
TUNER		O C	0233	87-A10-577-010	CAP,CER 0.022-50 Z YF	a	b	c
TUNER		O C	0234	87-A10-577-010	CAP,CER 0.022-50 Z YF	a	b	c
TUNER		O CF	0201	87-008-582-010	FLTR,CER SFU455B	a	b	c

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL		
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
TUNER		O	CF 0202	87-008-261-010	FLTR,CF SFE10.7MA5	a	b	c
TUNER		S	D 0201	87-070-345-080	DIODE,1N4148	a	b	c
TUNER		S	D 0202	87-070-345-080	DIODE,1N4148	a	b	c
TUNER		S	IC 0201	87-A21-271-010	IC,TA2111N	a	b	c
TUNER		O	L 0202	8B-CDC-639-010	COIL,FMOSC3T5MM	a	b	c
TUNER		O	L 0203	8B-CDC-639-010	COIL,FMOSC3T5MM	a	b	c
TUNER		O	L 0204	8B-CDC-639-010	COIL,FMOSC3T5MM	a	b	c
TUNER		O	L 0205	8B-CDC-639-010	COIL,FMOSC3T5MM	a	b	c
TUNER		O	L 0206	8B-CDC-639-010	COIL,FMOSC3T5MM	a	b	c
TUNER		O	L 0208	87-005-849-080	COIL,10UH K CECS	a	b	c
TUNER		X	R 0201	88-121-102-080	RES,1K-1/8W J	a	b	c
TUNER		X	R 0202	88-121-331-080	RES,330-1/8W J	a	b	c
TUNER		X	R 0203	88-121-222-080	RES,2.2K-1/8W J	a	b	c
TUNER		X	R 0204	88-121-222-080	RES,2.2K-1/8W J	a	b	c
TUNER		X	R 0205	88-121-332-080	RES,3.3K-1/8W J	a	b	c
TUNER		X	R 0206	88-121-332-080	RES,3.3K-1/8W J	a	b	c
TUNER		X	R 0207	88-121-332-080	RES,3.3K-1/8W J	a	b	c
TUNER		X	R 0208	88-121-331-080	RES,330-1/8W J	a	b	c
TUNER		X	R 0210	88-121-560-080	RES,56-1/8W J	a	b	c
TUNER		X	R 0211	88-121-104-080	RES,100K-1/8W J	a	b	c
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
TUNER		X	R 0212	88-121-104-080	RES,100K-1/8W J	a	b	c
TUNER		X	R 0225	88-121-560-080	RES,56-1/8W J	a	b	c
TUNER		X	R 0230	88-121-154-080	RES,150K-1/8W J	a	b	c
TUNER		O	T 0201	8B-CDC-672-010	COIL,AM OSC	a	b	c
TUNER		O	T 0202	8B-CDC-672-010	COIL,AM OSC	a	b	c
TUNER		O	T 0203	8B-CDC-672-010	COIL,AM OSC	a	b	c
TUNER		O	VC 0201	8B-CDC-671-010	TUN-CAP,20P-126P DF443DF02-A04	a	b	c

MECHANICAL PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL		
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
APPEARANCE		O	MC1001	8C-CDC-004-010	LID,CD S	.	b	.
APPEARANCE		O	MC1002	8C-CDC-005-010	LID,CASS SD	.	b	.
APPEARANCE		O	MC1003	8C-CDC-006-010	POINTER,TU	a	b	c
APPEARANCE		O	MC1004	8C-CDC-008-010	WINDOW,DISP S	a	b	c
APPEARANCE		O	MC1005	8C-CDC-011-010	WINDOW,TUS K	a	b	c
APPEARANCE		O	MC1006	8C-CDC-030-010	CABI,FR ASSY T	a	.	c
APPEARANCE		X	MC1007	8C-CDC-031-010	CABI,FRONT T	a	.	c
APPEARANCE		O	MC1008	8C-CDC-032-010	CABI,REAR T	a	.	c
APPEARANCE		O	MC1009	8C-CDC-033-010	LID,CD T	a	.	c
APPEARANCE		O	MC1010	8C-CDC-034-010	LID,CASS TD	a	.	c
APPEARANCE		O	MC1011	8C-CHC-006-010	CHAS,CD	.	b	.
APPEARANCE		O	MC1012	8C-CHC-008-010	WINDOW,CASS	a	b	c
APPEARANCE		X	MC1013	8C-CHC-020-010	GRILLE,L T	a	.	c
APPEARANCE		X	MC1014	8C-CHC-021-010	GRILLE,R T	a	.	c
APPEARANCE		O	MC1015	8C-CHC-022-010	ARM,HANDLE T	a	.	c
APPEARANCE		O	MC1016	8C-CHC-024-010	CHAS,CD T	a	.	c
APPEARANCE		X	MC1017	8C-CHC-046-010	GRILLE,L S	.	b	.
APPEARANCE		X	MC1018	8C-CHC-047-010	GRILLE,R S	.	b	.
APPEARANCE		O	MC1019	8C-CHC-048-010	ARM,HANDLE S	.	b	.
APPEARANCE		O	MC1020	8C-CDC-001-010	CABI,FR ASSY S	.	b	.
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
APPEARANCE		X	MC1021	8C-CDC-002-010	CABI,FRONT S	.	b	.
APPEARANCE		O	MC1022	8C-CDC-003-010	CABI,REAR S	.	b	.
APPEARANCE		O	MC1023	8C-CHC-009-010	COVER, BATT T	a	.	c
APPEARANCE		O	MC1024	8C-CHC-036-010	COVER, BATT S	.	b	.
KNOB		O	MC1025	8C-CDC-007-010	KNOB,RTRY TU S	.	b	.
KNOB		O	MC1026	8C-CDC-036-010	KNOB,RTRY TU T	a	.	c
KNOB		O	MC1027	8C-CHC-010-010	KNOB,SL FUNC T	a	.	c
KNOB		O	MC1028	8C-CHC-011-010	KNOB,RTRY VOL T	a	.	c
KNOB		O	MC1029	8C-CHC-012-010	KEY,CASS PAUSE T	a	.	c
KNOB		O	MC1030	8C-CHC-013-010	KEY,CASS STOP T	a	.	c
KNOB		O	MC1031	8C-CHC-014-010	KEY,CASS FF T	a	.	c
KNOB		O	MC1032	8C-CHC-015-010	KEY,CASS REW T	a	.	c
KNOB		O	MC1033	8C-CHC-016-010	KEY,CASS PLAY T	a	.	c
KNOB		O	MC1034	8C-CHC-017-010	KEY,CASS REC T	a	.	c
KNOB		O	MC1035	8C-CHC-018-010	KEY,CONT	a	b	c
KNOB		O	MC1036	8C-CHC-019-010	KNOB,SL BASS T	a	.	c
KNOB		O	MC1037	8C-CHC-037-010	KNOB,SL FUNC S	.	b	.
KNOB		O	MC1038	8C-CHC-038-010	KNOB,RTRY VOL S	.	b	.
KNOB		O	MC1039	8C-CHC-039-010	KEY,CASS PAUSE S	.	b	.
KNOB		O	MC1040	8C-CHC-040-010	KEY,CASS STOP S	.	b	.
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
KNOB		O	MC1041	8C-CHC-041-010	KEY,CASS FF S	.	b	.
KNOB		O	MC1042	8C-CHC-042-010	KEY,CASS REW S	.	b	.
KNOB		O	MC1043	8C-CHC-043-010	KEY,CASS PLAY S	.	b	.
KNOB		O	MC1044	8C-CHC-044-010	KEY,CASS REC S	.	b	.
KNOB		O	MC1045	8C-CHC-045-010	KNOB,SL BASS S	.	b	.
PLATE		X	MC1046	87-057-961-010	LBL,CAUTION TRIANGLE	a	b	c
PLATE		X	MC1047	87-057-995-010	LBL,CAUTION EFSD	a	b	c
PLATE		X	MC1048	87-B40-154-010	LBL,BAR-CODE CU	a	b	c
PLATE		X	MC1049	87-B40-281-010	LBL,BAR-CODE A 35X8	a	b	c
PLATE		X	MC1050	8A-CH4-040-010	LBL,CAUTION RW E	a	b	c
PLATE		X	MC1051	8C-CDC-051-010	LBL,SPEC K	a	.	.
PLATE		X	MC1052	8C-CDC-052-010	LBL,SPEC EZ	.	b	c
PLATE		O	MC1053	8C-CHC-219-010	PLATE,AC COVER	a	b	c
CD		O	MC1054	M8-CZK-490-070	KSM-213RDM	a	b	c
TAPE		X	MC1055	M8-AZK-890-070	TN-21ZVC-2000	a	b	c
OTHERS		O	MC1056	82-CD8-212-010	SPR-T,CAM CD	a	b	c
OTHERS		O	MC1057	86-CS3-211-010	COVER, AC SOCKET	a	b	c
OTHERS		O	MC1058	86-CS3-216-010	HLDR,BAR ANT	a	b	c
OTHERS		O	MC1059	87-036-368-010	MAGNET,	a	b	c
OTHERS		O	MC1060	8B-CDC-048-010	PANEL,CD(SONY)	a	b	c
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
OTHERS		O	MC1061	8B-CDC-207-010	BASE,CHUCK	a	b	c
OTHERS		O	MC1062	8B-CDC-210-010	CUSHION,CD	a	b	c
OTHERS		O	MC1063	8C-CDC-204-010	LEVER,CD LOCK	a	b	c
OTHERS		O	MC1064	8C-CHC-203-010	SPR-T,BATT A	a	b	c
OTHERS		X	MC1065	8C-CHC-207-010	HLDR,LCD	a	b	c
OTHERS		O	MC1066	8C-CHC-208-010	SPR-T,CASS	a	b	c
OTHERS		O	MC1067	8C-CHC-209-010	SPR-T,CD	a	b	c
OTHERS		O	MC1068	8C-CHC-211-010	GEAR,OIL DAMP ALCO	a	b	c
OTHERS		O	MC1069	8C-CHC-212-010	SPR-P,ANT	a	b	c
OTHERS		O	MC1070	8C-CHC-215-010	NUT,3-5.5-2	a	b	c
OTHERS		O	MC1071	8C-CHC-216-010	W,2.8-9.5-0.8	a	b	c
OTHERS		O	MC1072	8C-CHC-217-010	W,3.2-12-0.8	a	b	c
OTHERS		O	MC1073	8B-CDC-206-010	HLDR,CHUCK	a	b	c
OTHERS		O	MC1074	8B-CDC-208-010	PLATE,CHUCK	a	b	c
OTHERS		X	MC1075	8B-CDC-209-010	SH,CHUCK	a	b	c
OTHERS		O	MC1076	8B-CDC-211-010	S-SCREW,CD	a	b	c
OTHERS		X	MC1077	8C-CDC-203-010	HLDR,TU	a	b	c
OTHERS		O	MC1078	8C-CDC-205-010	HLDR,CD LOCK	a	b	c
OTHERS		X	MC1079	8C-CHC-205-010	HLDR,SPKR A	a	b	c
OTHERS		O	MC1080	8C-CHC-210-010	HLDR,DAMP GEAR ALCO	a	b	c

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL		
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
SCREW		O	MC1081	87-261-096-410	V+3-10	a	b	c
SCREW		O	MC1082	87-721-074-410	QT2+2.6-8 W/O SLOT	a	b	c
SCREW		O	MC1083	87-741-073-410	UT2+2.6-6 W/O SLOT	a	b	c
SCREW		O	MC1084	87-741-102-410	UT2+3-20 W/O SLOT	a	b	c
SCREW		O	MC1085	87-741-104-410	UT2+3-30 W/O SLOT	a	b	c
SCREW		O	MC1086	87-744-094-410	UT2+3-6 W/O SLOT CR	a	b	c
SCREW		O	MC1087	87-744-095-410	UT2+3-8 W/O SLOT CR	a	b	c
SCREW		O	MC1088	87-261-035-410	V+2-6	a	b	c
SCREW		O	MC1089	87-741-096-410	UT2+3-10 W/O SLOT	a	.	.
SCREW		O	MC1090	87-741-096-410	UT2+3-10 W/O SLOT	.	b	.
SCREW		O	MC1091	87-741-096-410	UT2+3-10 W/O SLOT	.	.	c
ELECTRICAL		O	MC1092	87-A60-178-010	JACK,AC E BLK W/SW	a	b	c
ELECTRICAL		O	MC1093	87-A90-133-010	SW,LEAF LSA1120JAU	a	b	c
ELECTRICAL		O	MC1094	8B-CDC-610-010	PT,E	a	b	c
ELECTRICAL		O	MC1095	8B-CDC-625-010	SPKR, 8OHM BCD-C	a	b	c
ELECTRICAL		O	MC1096	8B-CDC-642-010	BAR-ANT,AM	a	b	c
ELECTRICAL		O	MC1097	8B-CDC-662-010	F-CABLE ASSY,2P 2 110MM	a	b	c
ELECTRICAL		O	MC1098	8B-CDC-665-010	FF-CABLE,16P 1 200MM	a	b	c
ELECTRICAL		X	MC1099	8B-CDC-666-010	SHLD WIRE,164 8 3C HEAD	a	b	c
ELECTRICAL		O	MC1100	8B-CDC-679-010	ANT,ROD FM	a	b	c
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
ELECTRICAL		X	MC1101	8B-CDC-680-010	HT-SINK,REG	a	b	c
ELECTRICAL		X	MC1102	8B-CDC-681-010	HT-SINK,AMP	a	b	c
ELECTRICAL		X	MC1103	8B-CDC-682-010	WIRE,ANT4-50-5/5	a	b	c
ELECTRICAL		X	MC1104	8B-CDC-687-010	SHLD-SH,PT	a	b	c
ELECTRICAL		O	MC1105	8C-CDC-621-010	CONN ASSY,4P SP	a	b	c

ACCESSORIES PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL		
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
ACCESSORY		O	1	87-A80-081-010	AC CORD SET ASSY,EZ BLK	a	b	c
ACCESSORY		O	2	87-099-726-010	PLUG,ADPTR CONV(K)	a	.	.
LBL,POP		X	3	8C-CDC-971-010	LBL,POP K	a	b	c
PACKING DU		X	4	87-056-600-010	LBL,L K	a	.	.
PACKING DU		X	5	87-056-770-010	LBL,COLOR L SIL	.	b	.
PACKING DU		X	6	8C-CDC-851-010	CUSHION,ASSY CCDC	a	b	c
PACKING DU		X	7	8C-CDC-854-010	CTN,PRINTED EZSTC	a	b	c
PACKING DU		X	8	8C-CDC-855-010	CTN,OUTER KSTC	a	.	.
PACKING DU		X	9	8C-CDC-856-010	CTN,OUTER EZSTC	.	.	c
PACKING DU		X	10	8C-CDC-857-010	CTN,OUTER EZSC	.	b	.
PRINTED DU		X	11	87-056-168-010	SH,CAUTION INF-WARR(EC)	a	b	c
PRINTED DU		X	12	87-B40-085-010	BAG,PV 0.04-200-350 PL	a	b	c
PRINTED DU		X	13	87-B50-079-010	LIST,FACILITY(B)-0007	a	b	c
PRINTED DU		O	14	8C-CDC-905-010	IB,K(E)AL CSD-A190	a	.	.
PRINTED DU		O	15	8C-CDC-906-010	IB,EZ(9L)AL CSD-A190	.	b	c

OTHER PARTS LIST

! = ⚠ SAFTY PARTS
C = Components marked
All components used on this model at the production line are shown in this service manual.
However, please note that not all components will be available as spare parts for after-sales service.
Components marked S and O are designated as spare parts for service and will be stocked at the spare parts centers.
Components marked X and R are not designated as spare parts for after sales service, and will not be stocked at the spare parts centers.

UNIT-NAME	!	C	REF-NO	PARTS-NO	PARTS-NAME	SUFFIX&MODEL		
						CSD-A190 KSTC	CSD-A190 EZSC	CSD-A190 EZSTC
PWB		X		8C-CDC-603-010	PWB,BATT	a	b	c
PWB		X		8C-CDC-601-010	PWB,COMB MAIN	a	b	c
PWB		X		8C-CDC-604-010	PWB,DISP	a	b	c
PWB		X		8C-CDC-602-010	PWB,MAIN	a	b	c

SCHEMATIC DIAGRAM – 1 (CD / LED DISPLAY)



SCHEMATIC DIAGRAM – 2 (RADIO / TAPE / POWER AMP)



アイワ株式会社
AIWA CO.,LTD.
〒110-8710 東京都台東区池之端1-2-11 ☎03(3827)3111 (代表)
2-11, IKENOHATA 1-CHOME, TAITO-KU, TOKYO 110-8710, JAPAN TEL:03 (3827) 3111

2000075